

**Streamer User Manual** 



# **TABLE OF CONTENTS**

- 1.0 Introduction
- 2.0 Package contents
- 3.0 Important safety instructions
- 4.0 Front Panel
- 5.0 Back Panel
- 6.0 Installation
- 7.0 LED
- 8.0 Download the APP
- 9.0 Connecting
- 10.0 Specifications
- 11.0 Troubleshooting
- 12.0 Warranty
- 13.0 Note



#### 1.0 INTRODUCTION

Welcome to EarMen Family.

EarMen Staccato is audio streaming device which allows you to listen to the music of your life. Staccato is sophisticated Internet Streaming device that allows you to listen to a wide range of Internet music service providers.

You can stream from any source in your wireless network. However you want to stream music, Staccato will provide outstanding performance and we are sure you will enjoy it.

#### 2.0 PACKAGE CONTENT

EarMen Staccato Streamer Bluetooth antenna User manual

Retain the packing materials for future use. Retain the user manual and information concerning the date and place of purchase of your equipment for further reference.




### 3.0 IMPORTANT SAFETY INSTRUCTIONS

- Please read these instructions carefully before commencing installation. They provide full guidance to help you install your streamer safely and correctly.
- Keep these instructions.
- · Heed all warnings.
- Follow all instructions.
- Clean only with dry cloth. Unplug this product from the mains before cleaning.
- Do not install near any heat sources such as radiators, heat registers, stoves or any other apparatus that produce heat.
- Do not use this product near water.
- Do not defeat the safety purpose of the polarized or grounding-type plug. USA and Canada only: A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- · Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- WARNING: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases, should not be placed on this apparatus.
- To completely disconnect this equipment from the mains, disconnect the power supply cord plug from the receptacle
- The mains plug of the power supply cord shall remain readily operable.
- The unit must be mounted on a solid, level and stabile surface.
- Before you connect the device to AC mains power, ensure your AC mains voltage corresponds to the product.



# **4.0 FRONT PANEL**




- 1. ON/OFF Button

  Press and hold power button for 2 second to turn ON/OFF the device
- 2. Bicolor LED Red/Blue



### **5.0 BACK PANEL**





### 6.0 INSTALLATION

Connect your EarMen Staccato streamer from the desired output to your system, and plug in the network cables into your Staccato. Make sure you have the Staccato and your source device connected to the same network source.

Feel free to contact the EarMen Customer Service department for any further questions or for additional assistance at support@earmen.com

### 7.0 LED

When device is turned ON, blue LED will blink as notification that device is searching for network. After a while if there is internet connection (LAN cable connected) blue LED will stay ON without blinking. If LAN cable is disconnected from device, LEDs will signal it as RED -BLUE-RED-BLUE.

When device is turning off, after power button press, RED led will be turned on as notification that device is entering shut down procedure. After a while, when Staccato is turned off, RED diode turns off.

#### 8.0 DOWNLOAD THE EARMEN APP


Find and Download EarMen Stream App on App Store and Google Play







# 9.0 CONNECTING





**9.1** Open EarMen Stream App and select EarMen Staccato Streamer

Make sure you have the Streamer and your device connected to the same network source!



- **9.2.** Select the Service of your choice
- **9.2.1.** If you want to listen the music from TIDAL music service, click on TIDAL and than, select the link to connect the Staccato with your TIDAL account.








Enter your TIDAL account user nama and password, and after successfully linked, you are ready!








Tidal Terms & Conditions can be found here: https://tidal.com/terms



**9.2.3.** If you want to listen music from Spotify, open the Spotify App.





Connect instructions: Use your phone, tablet or computer as a remote control for Spotify.

Go to https://www.spotify.com/us/connect/to learn how.



The Spotify Software is subject to third party licenses found here:

www.spotify.com/connect/third-party-licenses

10



**9.2.3.1.** Play the song you want, and if you haven't connected to EarMen Staccato, click on the icon in the lower left corner and select "Staccato"







## 10.0 SPECIFICATIONS

Input Power: AC/DC power adapter 9-12V DC / 2A

Input Connectors: 1 x LAN, 1 x USB 2.0 Output Connectors: 1 x TOS Link, 1 x RCA

Ethernet: 10/100Mbps

Bluetooth: Bluetooth LE 4.2 (BDR/EDR)
Dimensions L x W x H (mm): 150 x 150 x 30

#### 11.0 TROUBLESHOOTING

If you experience any trouble with your Staccato, contact us on: support@earmen.com

- 1. Staccato is not connected to your network
- make sure the LAN cable is connected properly
- make sure the LAN cable source is connected to the Internet
- 2. Staccato is having a problem connecting the local USB Media
- check if Staccato is capable of playing the current file type
- 3. There is no power
- ensure the AC power cord is connected properly
- ensure the plug is fully inserted into the wall socket
- 4. There is no sound
- check the source component is properly connected
- · check your speakers are properly connected
- 5. There is no sound on one channel
- · check speaker connections
- · check interconnects
- 6. There is lod buzz or hum
- ensure no interconnects are loose or defective



#### 12.0 WARRANTY

Product you have purchased is designed to give you enjoyment in your favorite music. However it is possible that the failure occurs even at this precise-made, high quality equipment. In this case, please read the enclosed warranty carefully which contains rights, limitations, exclusions and obligation.

#### EarMen LLC warranty terms and condition

- Please register your product within 30 days of purchase, otherwise the warranty will not apply.
- EarMen products come with a two years limited warranty against defects in materials and workmanship.
- Guarantee service is available only in the region/country of original sale
- The guarantees start from the invoice-issue date
- · Original invoice must be produced for the authentication prior to any warranty claim.
- Warranty is provided to the original owner only and is not transferable to any third party.
- The warranty does not cover:
- (a) if the EarMen product is stored in a humid environment
- (b) which has not been maintained in accordance with any operating or handling instructions provided by EarMen LLC
- (c) which has been used other than in accordance with the product operating and handling instructions
- (d) any service or modification performed by an unauthorized person or company
- (e) any product not purchased from EarMen or an a EarMen Authorized Partner
- (f) repair work performed by the end user or any non-authorized repair center.
- (g) normal wear tear and cosmetic damage
- (h) product sold "as is", "as seen"
- (i) connected equipment
- (j) personal injury
- The limited warranty applies to the battery and is valid for 6 months
- EarMen will during the warranty period repair the product to working order or if this is not possible, EarMen will be replaced the product with the same one or the similar available product.
- Any parts/device that are replaced will become the property of EarMen
- · After the warranty period, all the repairs and shipping cost will be charged to the owner.
- · Any repair or replacement under this warranty will not extend the prior of warranty.



#### **13.0 NOTE**

If you have any question regarding warranty condition in your area, contact us at: sales@earmen.com

For more visit earmen.com



This product should not be disposed with your household waste.

This product should be handed over to a designated collection point to be recycled.

EarMen LLC Chicago, IL, USA